2494 Transfer Instructions



1) When the roll of paper is at 3" Dia. Or smaller, it is time to replace it with a new roll.



2) Carefully remove the stub roll, making sure the paper web is under the transfer bar.



3) Insert stub roll into "stub roll holders" in the bottom of the dispenser.



4) Install a new roll with the web coming off the back. Place tail of paper under transfer bar.



5) Do not tuck transfer bar into paper, allow transfer bar to rest on web of new roll.



6) Close cover and resume dispensing. The new paper will transfer automatically when stub roll is used up.

Distributed by www.AmeraProducts.com Phone: (800) 608-6568 Fax: (409) 840-5545 info@ameraproducts.com